

# **MODIFICATION INSTRUCTIONS**

for the

## ***KODAK* MULTILOADER 300**

Service Code 3058

### **Modification No. 38**

#### **TYPE 2**

##### **PURPOSE:**

To ensure that the bottom FILM CHUTE SENSOR B35 detects all type of films.

SERIAL NUMBERS: up to SN 2130

INSTALLATION TIME: Approx. 1 hours

PARTS REQUIREMENTS: Modification Kit 9228706

**PLEASE NOTE**

The information contained herein is based on the experience and knowledge relating to the subject matter gained by Kodak prior to publication.

No patent license is granted by this information.

Kodak reserves the right to change this information without notice, and makes no warranty, express or implied, with respect to this information. Kodak shall not be liable for any loss or damage, including consequential or special damages, resulting from the use of this information, even if loss or damage is caused by Kodak's negligence or other fault.

**PARTS LIST**

<b>PART-NO.</b>	<b>DESCRIPTION</b>	<b>QUANTITY</b>
9228706.....	MOD KIT 32	

The KIT contains:

4521441.....	WIRE TIE SOCKET.....	1
6081850.....	WIRE TIE.....	1
9216202.....	MOUNTING BRACKET .....	1
9218701.....	ADAPTER CABLE .....	1

**INTRODUCTION**

For some very transparent films (for example AGFA DUPLIKAT FILM) the sensitivity of SENSOR B35 (Interface bottom) is too high. To reduce the sensitivity install the new (longer) SENSOR MOUNTING BRACKET and the ADAPTER CABLE. This Adapter contains a resistor with 100 Ohm.

## **INSTALLATION**

1. Switch off the ML300 .
2. Take off the PANELS.
3. Take off and discard the existing MOUNTING BRACKET of SENSOR B35.




figure 1

4. Mount SENSOR B35 onto the new (longer MOUNTING BRACKET. See the drawing on the next page.

### **CAUTION**

**Do not break the SENSOR WIRES.**




figure 2

5. Connect the new ADAPTER CABLE in between the SENSOR B35 and the existing CABLE. See the figure on the next page.
6. Fix the ADAPTER CABLE with the SELFADHESIVE WIRE TIE SOCKET and WIRE TIE to the FILM CHUTE.



## ADJUSTMENT OF SENSOR B35 FILM IN INTERFACE BOTTOM

### Purpose:

This adjustment ensures that all types of FILM are recognised in the bottom of the FILM CHUTE.

### CAUTION

Take proper ESD SAFETY PRECAUTIONS when doing this adjustment.

1. Ensure that the XML300 is switched off.
2. Pull out U41 off PCB A4.
3. Connect PIN 1 to PIN 3 at the SOCKET of U41.




figure 4

4. Connect the DVM to TP12 of PCB A4 and to TP11(GND PE) of PCB A4 (for the location of the TEST PINS see figure 5 for the wiring diagram see figure 3 ).







## **FINAL TEST**

1. Circle No.38 on the Modification Label.

from SN 1370

up to SN 1369




figure 7

2. Mount all PANELS
3. Run a few cycles to ensure proper operation.



**CUSTOMER EQUIPMENT SERVICES KODAK AG STUTTGART GERMANY**